

OSCILLATION WHEN ADJUSTING T3

This is a “last resort” fix for the problem of motor-boating when T3 is peaked.

Replace C68, C69 and C70 with **Polyphenylene sulfide (PPS) film capacitors**. When replacing the capacitors reconfigure the grounds per the drawings.

SEE: [Polyphenylene Sulfide \(PPS\) Film Capacitors – Mouser](#) for capacitor source.

